

# 加速度的读取

编写人：

批准人：

Copyright Conserved by  
Training Management Department  
For Training Purpose Only  
教材仅供培训中使用！  
不得用作工作依据！



# 概述

飞行过程中很多记录下的参数通过ACMS界面可以重新调阅和读取，不同的DFDAU其ACMS软件件号和MCDU上的页面也不同。当前MAX所使用的TELEDYNE的DFDAU，ACMS软件件号为BCG46-U000-01W3。

下面以垂直加速度为例，说明读取的方法。附件为可调阅的参数详情。



# 步骤

MCDU选择menu键



# 步骤

选择ACMS项



# 步骤

选择DISPLAY DATA项






# 步骤

选择DISP mnemonic




# 步骤

输入想要提取的参数



# 步骤

在页面中左侧横选按钮加载，右侧将列出记录的本段需再现的内容。





# 常用的加速度数据

VACMAX	VERTICAL ACCELERATION MAX FOR THIS SEC
VACMAX1	VERTICAL ACCEL. MAX ONE SEC BEFORE LAND
VACMAXL	VERTICAL ACCELERATION MAX AT FM=LAND
VACMIN	VERTICAL ACCELERATION MIN FOR THIS SEC
VACMIN1	VERTICAL ACCEL. MIN ONE SEC BEFORE LAND
VACMINL	VERTICAL ACCELERATION MIN AT FM=LAND



A light gray world map is centered in the background. Overlaid on the map are four red airplane icons and several red dashed lines that represent flight paths. The paths are curved and connect various parts of the world, including North America, Europe, Africa, and Australia. The word "Thanks" is written in a large, bold, red font across the center of the map.

Thanks